


# How to Install the Wood Photo Engraving Macro in CorelDRAW

- Open the CorelDRAW GMS folder for your version of CorelDRAW (X5, X6, X7, or X8). To open the GMS folder copy the folder address below that matches your version of CorelDRAW, and paste it into a Windows folder browser window.



## CorelDRAW X5:

C:\Users%\USERPROFILE%\AppData\Roaming\Corel\CorelDRAW Graphics Suite X5\Draw\GMS

## CorelDRAW X6:

C:\Users%\USERPROFILE%\AppData\Roaming\Corel\CorelDRAW Graphics Suite X6\Draw\GMS

## CorelDRAW X7:

C:\Users%\USERPROFILE%\AppData\Roaming\Corel\CorelDRAW Graphics Suite X7\Draw\GMS

## CorelDRAW X8:

C:\Users%\USERPROFILE%\AppData\Roaming\Corel\CorelDRAW Graphics Suite X8\Draw\GMS

- Copy the **Photo\_Wood\_EpilogLaser.gms** file from the unzipped folder into the CorelDRAW GMS folder.

To check that the installation worked start CorelDRAW, open the Macro Manager (Windows/Dockers/Macro Manager or Alt + Shift + F11), and you should now see the Wood Photo Macro in the Macro Manager.

To use the Macro, select the photo you would like to process and in the Macro Manager select the macro and double click or push the play button near the bottom of the Macro Manager.

